

HYDRA SMOOTH

INSTALLATION INSTRUCTIONS

For the most efficient operation, the **HYDRA SMOOTH** should be installed as close to lift cylinder as possible. Use the following instructions as a guide as they apply to most makes of front-end loaders. Installations can vary depending upon the make and model of the loader and/or tractor.

- Step 1. Determine hydraulic line diameter from lift cylinder to control valve.
- Step 2. With forks on the ground, disconnect the lift ram high-pressure line.
- Step 3. Install a tee adaptable to the existing lift line.
- Step 4. Reconnect lift line to tee.
- Step 5. Determine desired location of **HYDRA SMOOTH** keeping it as close to the lift cylinders as possible, and install new hydraulic line (length determined by location of **HYDRA SMOOTH**)



HYDRA SMOOTH CORPORATION
2826 State Hwy W
Ozark, MO 65721
417/581-1373